

# INSTALLATION INSTRUCTIONS FOR *EnerTrac* Propane Tank Transmitter

INSTALLS IN LESS THAN 5 MINUTES!

## MATERIALS:

- #1 Phillips Head Screw Driver
- P/N 0003822 Propane Transmitter

## STEP 1

A.) Remove propane transmitter from packaging and check for any damage.

REMOTE READY SENSOR



Do Not Push, Sensitive Components

## STEP 2

A.) Locate propane gauge on tank and note the position of the propane indicator.



**REQUIREMENT:** Propane gauge must be a **Remote Ready Gauge**. See gauge kit 0004264 for adapting a non-remote ready gauge

B.) Remove the gauge making sure to keep the original screws.



C.) Thread the Remote Ready Sensor through the top of the tank lid and snap it into the gauge and re-install on the propane tank. Make sure the propane gauge indicator returns to its original position.



## STEP 3

A.) **REMOVE** the ON/OFF magnet from the bottom of the propane transmitter to turn the unit on and apply extra bar code to customer paperwork.

B.) Attach the propane transmitter to the top of the propane tank lid making sure all three magnetic wings hold firmly. If the lid is plastic or fiberglass secure the transmitter with sheet metal screws through the indentation markings on the wings of the green case. (NOTE: Do NOT cover lid vent hole with propane transmitter when installing.)

C.) Close the tank lid making sure that all wires are carefully tucked away so they do not get crushed by the edge of the lid.



For more information, please contact:  
Enertrac Inc. 94 River Rd. Hudson, NH 03051  
(603) 880-8484 WWW.ENERTRAC.COM

**EnerTrac**  
Know When 2GO

### RADIO AND TELEVISION INTERFERENCE

NOTE: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a residential environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense. Changes and Modifications not expressly approved by EnerTrac, Inc. can void your authority to operate this equipment under Federal Communications Commission rules.

ENRTR 0003822 REV16